



## Timber Stud - Partition Detail

### Before you start installation

1. Prepare the Base Floor. It is important that the base floor is Clean (free from loose dirt and concrete dust), Flat (within National Building Standards +/- 5mm over a 5m span) and where possible, Dry.

### Installing the Regupol® Isolating Strip

1. Bond the **Regupol® Isolating Strip** to the base floor (please contact CMS Acoustics for a list of recommended adhesives). Bonding should be carried out in accordance with the adhesive manufacturer's instructions. Ensure that a sufficient width of **Regupol® Isolating Strip** is used for the partition and cladding. Any surplus material should be trimmed with a builder's knife.

2. Bond the timber stud to the **Regupol® Isolating Strip**. **Do not** use mechanical fixings such as screws or pins.

### NB

The recognized technical rules of the industry, and the code of practice requirements of BS8203:2001 "Installation of Resilient Floor Coverings" are to be observed.

### Installation Service

In addition to supply of this product CMS Acoustic Solutions offers a competitively-priced installation service anywhere in the UK. Use of our service ensures that installation is performed to the highest standards by tradesmen fully experienced in the specialist skills of fitting acoustic materials correctly. For further details contact our technical team on 01925 577711.

### ISOLATING STRIP DIMENSIONS

<b>Thickness</b>	<b>6mm</b>
<b>Widths</b>	<b>43mm</b>
	<b>100mm</b>
	<b>120mm</b>
	<b>200mm</b>
<b>Length</b>	<b>1250mm</b>

