



**Regupol® Kushin Pad** is primarily used as a high performance impact insulation material for loading bays in retail premises, mail distribution facilities, etc.

#### Before you lay Regupol® Kushin Pad

For loading bay applications, a 25mm deep, three sided recess should be formed in the concrete surface.

The cement sub floor should be smooth or levelling screed should be applied prior to installation, which must be dry and free from dust and debris.

#### Laying Regupol® Kushin Pad

Bond the **Regupol® Kushin Pad** into position, (please contact CMS Acoustics for recommended adhesives), taking care to follow the manufacturer's instructions.

Trim the edge of the **Regupol® Kushin Pad** flush with the front of the bay.

Allow 24 hours for the adhesive to cure before subjecting the **Regupol® Kushin Pad** to traffic. Cure time is dependent upon adhesive used, therefore please consult the adhesive manufacturer for full details.

#### Installation Service

In addition to supply of this product CMS Acoustic Solutions offers a competitively-priced installation service anywhere in the UK. Use of our service ensures that installation is performed to the highest standards by tradesmen fully experienced in the specialist skills of fitting acoustic materials correctly. For further details contact our technical team on 01925 577711.

### New Build Applications

