

Before you lay Regupol® 7210C

1. **Prepare the Base Floor.** It is important that the base floor is **Clean** (free from loose dirt and concrete dust), **Flat** (within National Building Standards $\pm 5\text{mm}$ over a 5m span) and where possible, **Dry**.

Laying Regupol® 7210C.

1. **The Regupol® 7210C** is supplied in sheet form. A sharp craft knife and straight edge must be used for cutting to size.

2. **Joints can be either overlapped or butt jointed (both along and across the sheet)**; if overlapped, the overlap must be at least 50mm. Overlaps and butt joints must be taped down using **Regupol® Hi-tack tape**.

3. **Turn up all perimeter edges** so that there will be at least 5mm of **Regupol®** above the finished screed. We recommend leaving a greater upturn and, if necessary, trimming to 5mm after the screed has set.


4. **Lay a waterproof membrane** (eg Visqueen), minimum of 0.2mm thick over the entire area. This must be overlapped by at least 100mm and must also cover the upturned edges of the **Regupol®**. All joints must be taped to prevent movement during the casting process.

You can now cast the screed taking the usual precautions to avoid damaging or moving the membrane and the **Regupol®**.


Installation Service

In addition to supply of this product CMS Acoustic Solutions offers a competitively-priced installation service anywhere in the UK. Use of our service ensures that installation is performed to the highest standards by tradesmen fully experienced in the specialist skills of fitting acoustic materials correctly. For further details contact our technical team on 01925 577711.

ALTERNATIVE JOINT DETAILS



TURN UP PERIMETER EDGES



NB

The **Regupol® 7210C** under screed acoustic material can be either overlapped or butt jointed. Both the screed thickness and method of installation must be advised by the contractor responsible for the screed package.